

LED PANEL LIGHT USER GUIDE

Safety Instruction:

Basic safety precautions should always be followed when installing, including the following:

- 1. Read instructions carefully before installing.
- 2. This LED Panel requires professional installation and maintenance.
- 3. The power supply of the LED Panel should be powered by a dedicated external LED driver.
- 4. Disconnect the power supply before installing or maintenance.
- 5. Make sure the wires have been properly connected before powering on the device.
- 6. Ensure the product has enough space for heat dissipation.
- 7. Ensure the luminaries are never covered by any heat insulation mat or slim layer material at anytime.
- 8. Dimmable version could be compatible with a wide range of recommended TRIAC dimmers.
- 9. IP40 for indoor use only, not for damp loaction; IP54 for indoor damp location.
- 10. Ambient Temperature: -10°C to + 45°C.
- 11. Storage Conditions: Cool & dry conditions.

Installation Procedure

WARNING:

1.Switch off before installation.








A CAUTION:

Make sure that the mounting surface or structural member used for installation can support the weight of LED Panel,

■ Recessed





Remove ceiling plaster slab.

② Connect the main AC wire L. N to the terminal of driver respectively. Connect the DC plug between driver and panel light.











Suspended





① Knock the plastic anchor into ceiling.





③ Hanging the panel light to the suspending wires, connect the DC plug between driver and panel light.





Warning:

Input wire diameter ≥0.75mm²;

Product modification and improper installation are not valid for warranty!