



Battery
Powered



WiFi



Decora®
Compatible

xPRESS



xPRESS

The Audio Keypad for Sonos®.



The xPress Audio Keypad is an entirely new way to control Sonos anywhere you are around the house. xPress is WiFi, battery-powered and magnetic allowing you to install it anywhere. Pair a keypad with any Sonos device and control your entire Sonos home sound system when grouped in party mode.

xPress is an official Endorsed Partner Integration with Sonos.



XPRESS AUDIO KEYPAD SPECIFICATIONS

XPRESS AUDIO KEYPAD



Dimensions

Weight: 0.1 lbs
Height: 2 5/8"
Width: 1 5/16"
Depth: 7/16"

What's in the Box

- Keypad
- Micro - USB to USB Cable
- 1G Decora Wall-plate adapter & hardware
- Quick Start Guide

#70800

BUTTONS



Play / Pause

Start your music with a touch of a button, anywhere you are. No need to take your phone out of your pocket.




Track Forward

Not feeling the current song? No worries, just hit the track forward button.



Favorites

Get direct, access to all of your Sonos favorites! Toggle between music stations such as Spotify and Pandora. It's all there at the touch of a button.



Volume

Need to quickly turn down the volume? Now you have the ability to. With volume buttons ready and on hand for when you need to answer the phone or turn up the party.

SETTING UP XPRESS

Use the iPort Connect iOS App to configure an xPress Audio Keypad in just a few minutes. Just tell the keypad what network you would like to join and which Sonos device to connect to. That's it. No programming or hub required.


1

Add Your Keypad to Your Network



2

Assign your Keypad to a Sonos Device



3

Choose a Great Spot to Install Your Keypad

